

PHONE: (303) 442-1255 • FAX: (970) 535-3114 • E-MAIL: itl@itlboulder.com • WEBSITE: www.itlboulder.com

REPORT NUMBER: ITL84961

PAGE: 1 OF 5

ISSUE DATE: 07/07/15

PREPARED FOR: PARSOURCE

CATALOG NUMBER: COMMERCIALLY AVAILABLE LUMINAIRE

LUMINAIRE: EXTRUDED WHITE PAINTED FINNED METAL BALLAST HOUSING WITH FABRICATED WHITE PAINTED FLAT METAL END CAPS, CAST WHITE PAINTED METAL SOCKET BRACKET/REFLECTOR MOUNTING ARM WITH FABRICATED WHITE PAINTED METAL REFLECTOR HOUSING, FABRICATED TEXTURED SPECULAR METAL REFLECTOR WITH FORMED TIERED SEMI-SPECULAR METAL LOWER REFLECTOR INSERT ON EACH SIDE OF LAMP. OPEN SIDES AND BOTTOM.

LAMP: ONE 1000-WATT CLEAR T-10 DOUBLE ENDED HIGH PRESSURE SODIUM, LIGHTS INTERACTION EPAPILLON 1000W EL PLUS, HORIZONTAL POSITION.

BALLAST: LIGHTS INTERACTION EPAPILLON 1000W,

BALLAST OUTPUT SETTING SET TO "1000" FOR THIS TEST.

INPUT ELECTRICAL: 240.0 VOLTS, 1024.8 WATTS, 4.29 AMPS

MOUNTING: SUSPENDED

NOTE: DATA SHOWN IS ABSOLUTE FOR THE SAMPLE PROVIDED AT RATED INPUT VOLTAGE (240VAC, 60Hz) TO THE BALLAST.

CANDELA DISTRIBUTION

					FLUX
0.0	25.0	45.0	65.0	90.0	
0	19337	19337	19337	19337	1918
5	19231	19498	19804	20121	6095
15	18680	20427	21679	22694	10494
25	17409	20390	23374	25142	14897
35	15435	20071	24483	27629	19438
45	13104	18697	25821	33335	24112
55	10628	18051	28341	35322	30792
65	7904	18056	30665	47509	23000
75	4012	12558	22033	22754	46000
85	402	2507	2284	1836	69000
90	8	1538	806	478	
95	1	1464	639	185	
105	0	78	693	211	
115	0	70	64	485	
125	0	67	61	53	
135	0	11	63	65	
145	0	2	23	70	
155	0	0	9	21	
165	0	0	0	2	
175	0	0	0	0	
180	0	0	0	0	

ZONAL LUMEN SUMMARY



ZONE	LUMENS	% FIXT
0 - 30	18507	14.2
0 - 40	33404	25.6
0 - 60	76954	59.0
0 - 90	129367	99.2
90-120	909	0.7
90-130	950	0.7
90-150	1003	0.8
90-180	1009	0.8
0-180	130376	100.0

EFFICACY = 127.2 lm/W

CIE TYPE - DIRECT

PLANE : 0-DEG 90-DEG

SPACING CRITERIA : 1.27 2.27



LEGEND:
0-deg -----
45-deg -----
90-deg -----

Checked	M KLOPF
Approved	R BEATTIE
Lighting Engineer	