

itl **boulder**
THE LIGHT CENTER OF THE INDUSTRY SINCE 1955

INDEPENDENT TESTING LABORATORIES, INC.
4066 CAMELOT CIRCLE, LONGMONT, CO 80504 USA

PHONE: (303) 442-1255 • FAX: (970) 535-3114 • E-MAIL: itl@itlboulder.com • WEBSITE: www.itlboulder.com

REPORT NUMBER: ITL84963

PAGE: 1 OF 4

ISSUE DATE: 07/15/15

PREPARED FOR: PARSOURCE

CATALOG NUMBER: COMMERCIALLY AVAILABLE LUMINAIRE

LUMINAIRE: FABRICATED WHITE PAINTED METAL BALLAST HOUSING, FABRICATED WHITE PAINTED METAL SOCKET BRACKET/REFLECTOR MOUNTING ARM, FABRICATED PEENED METAL REFLECTOR WITH PREMIUM SPECULAR FINISH. OPEN BOTTOM.

LAMP: ONE 1000-WATT CLEAR T-10 DOUBLE ENDED HIGH PRESSURE SODIUM, "SUPER HPS-1000W", HORIZONTAL POSITION.

BALLAST: GROWING SYSTEM ES-GS1000/DE, BALLAST OUTPUT SETTING SET TO "100%" FOR THIS TEST.

INPUT ELECTRICAL: 240.0 VOLTS, 987.1 WATTS,
4.20 AMPS

MOUNTING: SUSPENDED

NOTE: DATA SHOWN IS ABSOLUTE FOR THE SAMPLE PROVIDED AT RATED INPUT VOLTAGE (240VAC, 60Hz) TO THE BALLAST. UPPER HEMISPHERE LIGHT NOT MEASURED AT CLIENT'S REQUEST.

CANDELA DISTRIBUTION

					FLUX
0.0	25.0	45.0	65.0	90.0	
0	37230	37230	37230	37230	37230
5	37111	37027	36700	36225	35924
15	36569	34316	31119	29887	29237
25	34366	29541	27582	26807	25839
35	28140	24068	23667	23648	23617
45	20682	19196	20040	22420	24096
55	13961	13959	18383	32793	35913
65	9937	11191	20220	16821	16350
75	4545	6452	3852	2039	2084
85	539	512	466	501	516
90	6	20	44	47	31



ZONAL LUMEN SUMMARY

ZONE	LUMENS	% FIXT
0 - 30	25684	26.7
0 - 40	41020	42.6
0 - 60	76604	79.6
0 - 90	96214	100.0
90-180	0	0.0
0-180	96214	100.0

EFFICACY = 97.5 lm/W

CIE TYPE - DIRECT

PLANE : 0-DEG 90-DEG
SPACING CRITERIA : 1.24 0.96



LEGEND:
0-deg -----
45-deg - - - -
90-deg - - - -

Checked	<i>M KLOPF</i>
Approved	<i>R BEATTIE</i> Lighting Engineer