

**itl** **boulder**  
THE LIGHT CENTER OF THE INDUSTRY SINCE 1955

INDEPENDENT TESTING LABORATORIES, INC.  
4066 CAMELOT CIRCLE, LONGMONT, CO 80504 USA

PHONE: (303) 442-1255 • FAX: (970) 535-3114 • E-MAIL: itl@itlboulder.com • WEBSITE: www.itlboulder.com

REPORT NUMBER: ITL84950

PAGE: 1 OF 4

ISSUE DATE: 07/06/15

PREPARED FOR: PARSOURCE

CATALOG NUMBER: COMMERCIALLY AVAILABLE LUMINAIRE

LUMINAIRE: EXTRUDED WHITE PAINTED FINNED METAL BALLAST HOUSING WITH  
FABRICATED WHITE PAINTED FLAT METAL END CAPS, CAST WHITE PAINTED  
METAL SOCKET BRACKET/REFLECTOR MOUNTING ARM, FABRICATED PEENED METAL  
REFLECTOR WITH FLAT PREMIUM SPECULAR METAL END CAPS. OPEN BOTTOM.

LAMP: ONE 1000-WATT CLEAR T-10 DOUBLE ENDED HIGH PRESSURE SODIUM, NANOLUX  
1000W DE HPS, HORIZONTAL POSITION.

BALLAST: NANOLUX SUPER DE 1000W, BALLAST OUTPUT SETTING SET TO "1000" FOR  
THIS TEST.

INPUT ELECTRICAL: 240.0 VOLTS, 1042.5 WATTS,  
4.35 AMPS

MOUNTING: SUSPENDED

NOTE: THIS IS A RELATIVE PHOTOMETRIC TEST  
PERFORMED AT RATED INPUT VOLTAGE  
(240VAC, 60Hz) TO THE BALLAST. LAMP  
INFORMATION PROVIDED BY CLIENT. UPPER  
HEMISPHERE LIGHT NOT MEASURED AT  
CLIENT'S REQUEST.

REPORT IS BASED ON 160300 LUMENS PER LAMP.

#### CANDELA DISTRIBUTION

#### FLUX

|    | 0.0   | 25.0  | 45.0  | 65.0  | 90.0  |       |
|----|-------|-------|-------|-------|-------|-------|
| 0  | 32624 | 32624 | 32624 | 32624 | 32624 |       |
| 5  | 32713 | 32845 | 33333 | 33761 | 34058 | 3193  |
| 15 | 32655 | 34585 | 32345 | 31701 | 31379 | 9214  |
| 25 | 30110 | 29801 | 31098 | 31447 | 29680 | 14159 |
| 35 | 24097 | 25189 | 29684 | 39934 | 42185 | 19948 |
| 45 | 17726 | 22093 | 38657 | 46536 | 41735 | 25269 |
| 55 | 14896 | 21626 | 32882 | 35229 | 36121 | 25842 |
| 65 | 9173  | 16953 | 27154 | 43594 | 39466 | 26051 |
| 75 | 2555  | 6558  | 12586 | 6246  | 3375  | 8807  |
| 85 | 152   | 66    | 191   | 308   | 274   | 364   |
| 90 | 1     | 6     | 22    | 27    | 1     |       |



#### ZONAL LUMEN SUMMARY

| ZONE   | LUMENS | %LAMP | %FIXT |
|--------|--------|-------|-------|
| 0 - 30 | 26565  | 16.6  | 20.0  |
| 0 - 40 | 46513  | 29.0  | 35.0  |
| 0 - 60 | 97624  | 60.9  | 73.5  |
| 0 - 90 | 132846 | 82.9  | 100.0 |
| 90-180 | 0      | 0.0   | 0.0   |
| 0-180  | 132846 | 82.9  | 100.0 |

TOTAL LUMINAIRE EFFICIENCY = 82.9 %

CIE TYPE - DIRECT

PLANE : 0-DEG 90-DEG  
SPACING CRITERIA : 1.24 1.93



|          |                   |
|----------|-------------------|
| Checked  | <i>M KLOPF</i>    |
| Approved | <i>R BEATTIE</i>  |
|          | Lighting Engineer |