

PHONE: (303) 442-1255 • FAX: (970) 535-3114 • E-MAIL: itl@itlboulder.com • WEBSITE: www.itlboulder.com

REPORT NUMBER: ITL84960

PAGE: 1 OF 4

ISSUE DATE: 06/30/15

PREPARED FOR: PARSOURCE

CATALOG NUMBER: COMMERCIALLY AVAILABLE LUMINAIRE

LUMINAIRE: EXTRUDED WHITE PAINTED FINNED METAL BALLAST HOUSING WITH
FABRICATED WHITE PAINTED FLAT METAL END CAPS, CAST WHITE PAINTED
METAL SOCKET BRACKET/REFLECTOR MOUNTING ARM, FABRICATED PEENED
PREMIUM SPECULAR METAL REFLECTOR WITH FLAT PREMIUM SEMI-SPECULAR
METAL END CAPS. OPEN BOTTOM.

LAMP: ONE 1000-WATT CLEAR T-10 DOUBLE ENDED HIGH PRESSURE SODIUM, GAVITA
1000W EL HPS K12X30S, HORIZONTAL POSITION.

BALLAST: GAVITA PRO 1000E DE US 120-240,

BALLAST OUTPUT SETTING SET TO

"1000" FOR THIS TEST.

INPUT ELECTRICAL: 240.0 VOLTS, 1065.0 WATTS,
4.50 AMPS

MOUNTING: SUSPENDED

NOTE: DATA SHOWN IS ABSOLUTE FOR THE SAMPLE
PROVIDED AT RATED INPUT VOLTAGE
(240VAC, 60Hz) TO THE BALLAST. UPPER
HEMISPHERE LIGHT NOT MEASURED AT
CLIENT'S REQUEST.

CANDELA DISTRIBUTION

	FLUX				
0.0	25.0	45.0	65.0	90.0	
0	26269	26269	26269	26269	26269
5	26137	26175	26542	26786	26990
15	25437	27071	28783	30703	32072
25	23734	26856	31427	33571	33849
35	21216	26160	30066	32472	32980
45	17319	23168	27851	36046	39798
55	13301	20154	30825	38021	40678
65	8539	19335	29552	31484	30600
75	4220	12909	14613	6313	4310
85	1139	562	198	75	37
90	4	12	32	22	0



ZONAL LUMEN SUMMARY

ZONE	LUMENS	% FIXT
0 - 30	24630	19.5
0 - 40	42761	33.9
0 - 60	90961	72.1
0 - 90	126094	100.0
90-180	0	0.0
0-180	126094	100.0

EFFICACY = 118.4 lm/W

CIE TYPE - DIRECT

PLANE : 0-DEG 90-DEG
SPACING CRITERIA : 1.27 2.11



Checked	<i>M KLOPF</i>
Approved	<i>R BEATTIE</i> Lighting Engineer