

PHONE: (303) 442-1255 • FAX: (970) 535-3114 • E-MAIL: itl@itlboulder.com • WEBSITE: www.itlboulder.com

REPORT NUMBER: ITL84959

PAGE: 1 OF 4

ISSUE DATE: 07/07/15

PREPARED FOR: PARSOURCE

CATALOG NUMBER: PHDEKTS1

LUMINAIRE: EXTRUDED WHITE PAINTED FINNED METAL BALLAST HOUSING WITH
FABRICATED WHITE PAINTED METAL END CAPS, FABRICATED WHITE PAINTED
METAL SOCKET BRACKET/REFLECTOR MOUNTING ARM, FABRICATED PEENED METAL
REFLECTOR WITH PREMIUM SPECULAR FINISH, OPEN BOTTOM.

LAMP: ONE 1000-WATT CLEAR T-10 DOUBLE ENDED HIGH PRESSURE SODIUM, AGROSUN
1000W 400V HIGH OUTPUT, HORIZONTAL POSITION.

BALLAST: PARSOURCE PHB3015, BALLAST OUTPUT SETTING SET TO "100%" FOR THIS
TEST.

INPUT ELECTRICAL: 240.0 VOLTS, 1048.2 WATTS,
4.41 AMPS

MOUNTING: SUSPENDED

NOTE: DATA SHOWN IS ABSOLUTE FOR THE SAMPLE
PROVIDED AT RATED INPUT VOLTAGE
(240VAC, 60Hz) TO THE BALLAST. UPPER
HEMISPHERE LIGHT NOT MEASURED AT
CLIENT'S REQUEST.

CANDELA DISTRIBUTION

					FLUX
0.0	25.0	45.0	65.0	90.0	
0	43172	43172	43172	43172	43172
5	42689	42813	42878	43121	43337
15	39498	40783	42976	44878	45848
25	36389	39528	45491	50647	51875
35	29837	38120	50217	58162	60552
45	20186	29403	51566	57283	50187
55	11394	19160	33966	33612	31743
65	5933	9386	18851	18964	9981
75	933	1785	2840	3915	3667
85	22	30	79	162	190
90	1	0	0	0	0



ZONAL LUMEN SUMMARY

ZONE	LUMENS	% FIXT
0 - 30	37154	26.5
0 - 40	66932	47.8
0 - 60	123044	87.8
0 - 90	140087	100.0
90-180	0	0.0
0-180	140087	100.0

EFFICACY = 133.6 lm/W

CIE TYPE - DIRECT

PLANE : 0-DEG 90-DEG
SPACING CRITERIA : 1.18 1.88



LEGEND:
0-deg -----
45-deg - - - -
90-deg - - - -

Checked	<i>M KLOPF</i>
Approved	<i>R BEATTIE</i>
Lighting Engineer	